

## V46 Series 2-Way Pressure-Actuated Water-Regulating Valves with Union Fittings

### Application

**⚠ WARNING**  
 This product is made of a copper alloy, which contains lead. The product is therefore not to be used on drinking water.

**IMPORTANT:** The V46 Series 2-Way Pressure-Actuated Water-Regulating Valves are intended to control water flow under normal equipment operating conditions. Where failure or malfunction of a V46 valve could lead to an abnormal operating condition that could cause personal injury or damage to the equipment or other property, other devices (limit or safety controls) or systems (alarm or supervisory) intended to warn of, or protect against, failure or malfunction of the V46 valve must be incorporated into and maintained as part of the control system.


The V46 direct-acting models open on a pressure increase. The V46 valves with union fittings are available in 1/2-in. through 1-1/4-in. sizes, and may be used with standard noncorrosive refrigerants.

### Installation

**IMPORTANT:** If these valves are installed on equipment that contains hazardous or regulated materials, such as refrigerants or lubricants, the installer and user should observe all regulations governing the handling and containment of those materials.

**IMPORTANT:** It is recommended to apply a nonhardening, pliable sealant (Loctite 567 or equivalent) to the face of the copper tailpiece to compensate for slight piping misalignments and surface imperfections on union ends.

### Dimensions




**Figure 1: V46 Valve Dimensions For Models With Union Fittings**  
 V46\_dim.cdr

**Table 1: V46 Valve Dimensions, inches (millimeters)**

Product Code Number	Nominal Valve Size	A	B	C	D	E
V46AJ-2C	1/2 in.	3-1/2 (89)	1-13/16 (47)	6-3/8 (162)	3-3/4 (96)	2-5/8 (67)
V46EK-2C	3/4 in.	3-13/16 (97)	2 (52)	6-13/16 (173)	4-3/16 (106)	2-5/8 (67)
V46AL-2C	1 in.	5-1/8 (130)	2-5/8 (67)	9-11/16 (246)	5-15/16 (151)	3-3/4 (95)
V46AM-2C	1-1/4 in.	5-3/16 (131)	2-5/8 (67)	10-1/8 (260)	6-3/16 (160)	3-15/16 (100)

**Manually Flushing the Valve**

Manually flush the valve and fluid piping before and after installing, repairing, or replacing a valve to remove filings, chips, or other foreign matter. Insert screwdrivers under both sides of the valve spring guide and lift upwards to flush the valve. See Figure 2. Manual flushing does not affect valve adjustment.



**Figure 2: Manual Flushing**  
V46\_union\_flush.cdr

**Location Considerations**

Install the valve vertically with the range adjustment screw on the top and the bellows and pressure connection line on the bottom to allow drainage of oil and refrigerant away from the valve bellows.

Do not mount the valve in any position other than vertical unless specified by the manufacturer of the equipment on which the valve is installed. Follow the manufacturer’s installation instructions.

Install the valve on the inlet side of the condenser. If it is necessary to keep the condenser flooded with water, install the valve on the outlet side of the condenser.

If the system is located in an area with high ambient temperatures, refrigerant head pressures may remain high enough during off cycles to prevent the valve from closing completely. In such instances, raise the opening point of the valve just enough to cause the valve to close flow to the condenser during compressor standby periods.

**Pressure Connections**

**! WARNING: Risk of Personal Injury.**  
To avoid possible personal injury, shut off the liquid supply and relieve the pressure before servicing the valve.

Connect the refrigerant-side flare connector to the appropriate high-side pressure tap point. If additional capillary tubing is necessary, use 1/4-in. tradesize copper tubing.

Follow the guidelines below when making pressure connections:

- **Use Pressure Tap Points Located on the Top Side of the Refrigerant Lines**  
This reduces the possibility of oil, liquids, or sediment accumulating in the pressure connection line or valve bellows, which could cause valve malfunction.
- **Avoid Sharp Bends in the Capillary Tubes**  
Sharp bends can weaken or kink capillary tubes, which may result in refrigerant leaks or restrictions.
- **Allow for Slack in the Capillary Tubes to Dampen Vibration**  
Mechanical vibration can weaken or damage the capillary tubes.



## Setup and Adjustments

The V46 valves are factory adjusted for the settings shown in Table 2.

The **opening point pressure** is the refrigerant pressure (at the valve's bellows) necessary to just lift the valve disc off of the valve seat and allow water to flow through the valve body. Turning the range adjustment screw changes the opening point pressure.

Use a standard service valve wrench or screwdriver to adjust the opening point pressure.

- Turn the range adjustment screw **counterclockwise to raise the opening point pressure.**
- Turn the range adjustment screw **clockwise to lower the opening point pressure.**

Use a refrigerant pressure gauge to adjust the opening point pressure. Operate the system at normal load conditions and adjust the valve's opening point to the desired pressure. See Table 2 for refrigerant pressure specifications.

## Flowcharts




Figure 4: 1/2-in. V46 ValveV46\_050flow.cdr




Figure 5: 3/4-in. V46 ValveV46\_075flow.cdr




Figure 6: 1-in. V46 ValveV46\_100flow.cdr




Figure 7: 1-1/4-in. V46 ValveV46\_125flow.cdr

## Repair and Replacement

The sensing element, internal parts, and the rubber diaphragm can be replaced.

For a replacement valve or replacement parts kit, contact the nearest Johnson Controls/PENN distributor. For replacement kit part numbers, refer to Table 3.

For replacement kit instructions and details, refer to the following bulletins:

- V46, V47, 246, and 247 Repair Parts and Service Instructions Repair Parts Bulletin (LIT-121695)
- V46, V47, V48, and V49 Sensing Element Replacement Technical Bulletin (LIT-121700)

Table 3: Repair and Replacement Kits

Valve Product Code Number	Nominal Size	Shipping Weight	Seat Repair Kit Product Code Number	Sensing Element Replacement Kit Product Code Number
V46AJ-2C	1/2 in.	2.7 lb (1.2 kg)	STT15A-602R	SEP77A-605R
V46EK-2C	3/4 in.	3.3 lb (1.5 kg)	STT16A-601R	SEP127A-600R
V46AL-2C	1 in.	8.3 lb (3.8 kg)	STT17A-609R	SEP107A-602R
V46AM-2C	1-1/4 in.	9.4 lb (4.3 kg)	STT17A-610R	

## Technical Data

<b>Product</b>	V46 Series 2-Way Pressure-Actuated Water-Regulating Valves
<b>Body Material</b>	1/2-in. and 3/4-in. Sizes - Cast Brass Bodies; 1-in. and 1-1/4-in. Sizes - Cast Iron Bodies with Rust-Resisting Finish
<b>Extension Sleeve, Disc, Stud, Disc Holder Material</b>	Brass
<b>Valve Seat Material</b>	Aluminum Bronze
<b>Valve Disc</b>	Buna-N
<b>Diaphragm</b>	Nylon Reinforced Buna-N
<b>Water Supply Pressure</b>	150 psig (1034 kPa) Maximum
<b>Water Supply Temperature</b>	170°F (77°C) Maximum
<b>Water Flow</b>	See Figures 4-7.
<b>Sensing Element</b>	Brass and Phosphor Bronze Bellows in Brass Cup
<b>Pressure Range</b>	See Table 2.
<b>Shipping Weight</b>	See Table 3.

*The performance specifications are nominal and conform to acceptable industry standards. For application at conditions beyond these specifications, contact Refrigeration Application Engineering at 1-800-275-5676. Johnson Controls shall not be liable for damages resulting from misapplication or misuse of its products.*



**Building Technologies & Solutions**  
507 E. Michigan Street, Milwaukee, WI 53202

*® Johnson Controls and PENN are registered trademarks of Johnson Controls in the United States of America and/or other countries. All other trademarks used herein are the property of their respective owners. © Copyright 2018 by Johnson Controls. All rights reserved.*